

INFORMATION FRÅN SVENSKA SKYDD

Huvudlåset

Det nedre låset med patentnyckel (lilla nyckeln) är ett "hemmalås". Det låses med vred från insidan när ni är hemma. När ni stänger dörren utifrån skall ni inte hålla ned handtaget. Då går dörren ej i lås.

När ni låst utifrån och trycker ned handtaget för att försäkra er om att dörren är låst så trycks dörren ut av spänningen i tätninglisten. Det gör att låset kan vara trögt att låsa upp

TRYCK TILL DÖRREN SÅ ATT NI HÖR ETT KLICKLJUD.

Inifrån drar ni handtaget till er tills ni hör ett klick. Då går låset tillbaka i rätt läge och dörren kan låsas upp utan problem.

Main lock

The lower lock, patent lock with small key, is a "being at home lock".

This lock is activated by operating a turning knob from inside the door when at home. When closing the door from outside don't press down the handle in order for the lock to get activated. When you have activated the lock from outside and then press the handle down to check that the door is locked, the door will be pressed outwards due to bias caused by the sealing gasket. This may cause the lock to be somewhat hard to unlock. Apply a light pressure on the door until a click sound appears. When activating the lock from inside (when at home) pull the door against you until the click sound appears.

The pressing or pulling of the door will make the lock to return to its correct position and the door can be unlocked without problems.

SVENSKA SKYDD

Stockholm tfn 08-562 270 00 Göteborg tfn 031-722 44 20 Malmö tfn 040-601 21 00